



PALFINGER CRANES MANUAL

by WSI Models

EXTENDING THE OUTRIGGERS

Slide out the outrigger and turn it down.



This manual can be used for all WSI PALFINGER projects



Before using the scale model, read the manual properly.

This product is very fragile, so use with care and with the right purpose.

TURN THE SUPPORT TO GROUND LEVEL

EXTENDING THE CRANE

The cylinder can be turned up and down. Lock it in place with the pin

Fold the crane upwards.









EXTENDING THE CRANE

Extend the boom sections.



OVERVIEW



MOUNTING THE OPTIONAL JIB

Twist the piston to unlock it and remove the top of the crane.

Replace it with the optional jib.





MOUNTING THE SWAP BODY

Click the kingpin on the bottom of the box into the fifth wheel, and slide forward.



